



# THE CHAIRMAN #118


## To open The Chairman




Step 1: Twist locks on back of chair legs to unlock.



Step 2: Pull the handles upward.



Step 3: Pull the arm of the chair up while pushing the bottom down.



Step 4: When chair is fully opened, apply locks to the chair frame.  
Reverse steps to close and lock.